

USER MANUAL

750 W AC Servo Motor and Drive Kit

MotionParts / SKU SERVO-0750-KIT / MPN MP-SV0750-23

Safety first

Read the complete manufacturer instructions and site safety procedure before installation. Isolate all electrical, hydraulic, pneumatic, thermal, and mechanical energy. Use qualified personnel and appropriate personal protective equipment.

Installation and commissioning

- 1 Installation and commissioning must be performed by qualified electrical personnel.
- 2 Isolate and verify all power sources before wiring the drive, motor, encoder, or brake circuits.
- 3 Provide protective earth, suitable overcurrent protection, and the clearances stated by the drive manufacturer.
- 4 Confirm motor parameters with the supplier before autotuning, then test at low speed without mechanical load.

Inspection and maintenance

Inspect the product at intervals appropriate to the application and duty cycle. Look for leakage, looseness, overheating, abnormal noise, corrosion, damaged wiring or seals, and any change in operating performance. Remove the product from service if safe operation is uncertain.

Support

For compatibility, replacement, or document-revision questions, quote SKU SERVO-0750-KIT and MPN MP-SV0750-23 when contacting the parts specialist.