

## USER MANUAL

# High-Pressure Three-Piece Ball Valve

ValvePro / SKU BV3000-12-SS316 / MPN BV3000-12

## Safety first

Read the complete manufacturer instructions and site safety procedure before installation. Isolate all electrical, hydraulic, pneumatic, thermal, and mechanical energy. Use qualified personnel and appropriate personal protective equipment.

## Installation and commissioning

- 1 Verify the ordered trim and pressure-temperature limits against the process conditions.
- 2 Fully depressurize and isolate the line before loosening any body or end-cap fastener.
- 3 Support connected pipework so external loads are not transferred to the valve body.
- 4 After installation, cycle the valve and hydrostatically test the assembly to the site procedure.

## Inspection and maintenance

Inspect the product at intervals appropriate to the application and duty cycle. Look for leakage, looseness, overheating, abnormal noise, corrosion, damaged wiring or seals, and any change in operating performance. Remove the product from service if safe operation is uncertain.

## Support

For compatibility, replacement, or document-revision questions, quote SKU BV3000-12-SS316 and MPN BV3000-12 when contacting the parts specialist.